

How to use the ET-1 Tuner

The ET-1 tuner is simple to operate and makes tuning very easy. You turn the tuner on by pushing the white button. The lights will flash to let you know that the tuner is on. The tuner will pick up the sound from your autoharp with either the built in microphone or if you have an electric autoharp you can plug it into the 1/4" input on the side. If you are using the built in microphone, you must tune your autoharp in a quiet room or the tuner will pick up background noise.

To tune, start by plucking the string that you want to. One of the 12 red lights will light up. This will show you the note you are playing. If the autoharp is extremely out of tune you may have to start by turning the tuning peg until the correct note is lit up. Once you have the correct note you can tell if the note is flat, in tune, or sharp using the LED light at the right of the tuner. If the note is flat the LED will flash yellow. The faster the LED light flashes yellow the more flat the note is. If the note is sharp the LED will flash red. The faster the LED light flashed red the more sharp the note is. If the LED is a solid Green the note is in tune. To turn off the tuner simply hold down the button until the 12 red lights flash.

